
CONTENDER

STEP UP TO THE PLATE



CONTENDER REFRIGERATOR TOPPING UNIT

RCG015 · RCG016 · RCG017 · RCG018 · RCG020



CONTENTS

1. SAFETY TIPS 3
2. PRODUCT DESCRIPTION 4
3. INTRODUCTION 4
4. PACK CONTENTS 4
5. INSTALLATION 5
6. OPERATION 7
7. CLEANING, CARE & MAINTENANCE 9
8. WIRING DIAGRAM 9
9. TROUBLESHOOTING 10
10. DISPOSAL 11
11. WARRANTY 11
12. COMPLIANCE 11



IMPORTANT

FOR YOUR SAFETY READ THE MANUAL CAREFULLY BEFORE INSTALLING OR USING THIS PRODUCT.
KEEP THE MANFUL WITH THE UNIT AT ALL TIMES FOR QUICK FUTURE REFERENCE.

I. SAFETY TIPS

POSITION ON A FLAT, STABLE SURFACE.

A SERVICE AGENT/QUALIFIED TECHNICIAN SHOULD CARRY OUT INSTALLATION AND ANY REPAIRS IF REQUIRED. DO NOT REMOVE ANY COMPONENTS OR SERVICE PANELS ON THIS PRODUCT.

CONSULT LOCAL AND NATIONAL STANDARDS TO COMPLY WITH THE FOLLOWING:

- HEALTH AND SAFETY AT WORK LEGISLATION
- FIRE PRECAUTIONS
- IEE WIRING REGULATIONS
- BUILDING REGULATIONS
- THE APPLIANCE IS INTENDED FOR COMMERCIAL USE.
- DO NOT ATTEMPT TO SERVICE THE ITEM YOURSELF.
- DO NOT USE DAMAGED APPLIANCES. IF YOU ARE IN ANY DOUBT, CONSULT SERVICE AGENT.
- DO NOT USE ELECTRICAL APPLIANCES INSIDE THE APPLIANCE (E.G. HEATERS, ICE-CREAM MAKERS ETC.), UNLESS THEY ARE OF THE TYPE RECOMMENDED BY THE MANUFACTURER.
- KEEP VENTILATION OPENINGS, IN THE APPLIANCE ENCLOSURE OR IN THE BUILT-IN STRUCTURE, CLEAR OF OBSTRUCTION.
- DO NOT USE MECHANICAL DEVICE OR OTHER MEANS TO ACCELERATE THE DEFROSTING PROCESS, OTHER THAN THOSE RECOMMENDED BY THE MANUFACTURER.
- DO NOT DAMAGE THE REFRIGERANT CIRCUIT.
- DO NOT STAND OR SUPPORT YOURSELF ON THE APPLIANCE OR GLASS PANEL.
- DO NOT ALLOW OIL OR FAT TO COME INTO CONTACT WITH THE PLASTIC COMPONENTS. CLEAN IMMEDIATELY IF CONTACT OCCURS.
- DO NOT PLACE COMBUSTION, EXPLOSIVE OR VOLATILE ARTICLE, CORROSIVE ACID OR ALKALI, OR LIQUID INTO THE UNIT.
- DO NOT USE THIS APPLIANCE TO STORE MEDICAL SUPPLIES.
- DO NOT USE JET/PRESSURE WASHERS TO CLEAN THE APPLIANCE.
- DO NOT ALLOW CHILDREN TO PLAY WITH THE PACKAGING, AND DESTROY PLASTIC BAGS SAFELY.
- ALWAYS CARRY, STORE AND HANDLE THE APPLIANCE IN A VERTICAL POSITION AND MOVE BY HOLDING THE BASE OF THE APPLIANCE.
- ALWAYS SWITCH OFF AND DISCONNECT THE POWER SUPPLY TO THE UNIT BEFORE CLEANING.
- KEEP ALL PACKAGING AWAY FROM CHILDREN. DISPOSE OF THE PACKAGING IN ACCORDANCE WITH THE REGULATIONS OF LOCAL AUTHORITIES.
- IF THE SUPPLY CORD IS DAMAGED, IT MUST BE REPLACED BY THE MANUFACTURER, ITS SERVICE AGENT OR SIMILARLY QUALIFIED PERSONS IN ORDER TO AVOID A HAZARD.
- THIS APPLIANCE IS NOT INTENDED FOR USE BY PERSONS (INCLUDING CHILDREN) WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES, OR LACK OF EXPERIENCE AND KNOWLEDGE, UNLESS THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY.
- CHILDREN SHOULD BE SUPERVISED TO ENSURE THAT THEY DO NOT PLAY WITH THE APPLIANCE.
- FOR INDOOR USED ONLY. NOT SUITABLE FOR INSTALLATION IN AN AREA WHERE A WATER JET COULD BE USED. MUST NOT BE CLEANED BY A WATER JET.
- TO GUARANTEE SAFE OPERATION, ENSURE THAT THE APPLIANCE IS SET UP AND CONNECTED AS DESCRIBED IN THE INSTRUCTION MANUAL.
- ANY REPAIRS AND WORK ON THE APPLIANCE SHOULD ONLY BE CARRIED OUT BY THE CUSTOMER SERVICE DEPARTMENT.
- DO NOT STORE EXPLOSIVE SUBSTANCES SUCH AS AEROSOL CANS WITH A FLAMMABLE PROPELLANT IN THIS APPLIANCE.

2. PRODUCT DESCRIPTION

	RCG0115	RCG0120	RCG0116	RCG0117	RCG0118
RATED POWER INPUT	160W				
RATED CURRENT	1.2A	1.3A			
POWER CONSUMPTION	1.0KWH/24H	1.2KWH/24H	1.3KWH/24H	1.4KWH/24H	
REFRIGERANT	R134A(120G)	R134A(125G)	R134A(130G)	R134A(155G)	
CLIMATIC CLASSIFICATION	4 (10°C -32°C)				
RATED FREQUENCY	50HZ				
RATED VOLTAGE	220-240V				
VOLUME	40 L	43 L	44 L	47 L	52 L
TEMPERATURE	2-10°C				
FOAMING AGENT	CP/IP				
NET WEIGHT	42KG	44KG	44KG	48KG	53KG
DIMENSION (LXWXH)(MM)	1200 X 335 X 225	1400 X 335 X 225	1500 X 335 X 225	1800 X 335 X 225	2000 X 335 X 225
ELECTRIC SHOCK PROTECTION CLASS	I				
NOISE	56DB				

3. INTRODUCTION

FOR YOUR SAFETY READ THE MANUAL CAREFULLY BEFORE ASSEMBLING OR USING THIS PRODUCT. SAVE THIS MANUAL FOR FUTURE REFERENCE. PLEASE TAKE A FEW MOMENTS TO CAREFULLY READ THROUGH THIS MANUAL. CORRECT MAINTENANCE AND OPERATION OF THIS MACHINE WILL PROVIDE THE BEST POSSIBLE PERFORMANCE FROM YOUR PRODUCT.

4. PACK CONTENTS

ONE CARTON BOX:

- HORIZONTAL SHOWCASE X1
- INSTRUCTION MANUAL X1
- GN CONTAINER ADAPTOR BAR

ONE WOODEN BOX:

- BRACKETS X 7
- GRUB SCREWS X 7
- TOP GLASS PANEL
- REAR GLASS PANEL
- SIDE GLASS PANELS X 2
- SCREWS X 12
- BUSHES X 14
- GN CONTAINER ADAPTOR BAR
- COLLARS X 6
- ADJUSTABLE FEET X4

WE PRIDE OURSELVES ON QUALITY AND SERVICE, ENSURING THAT AT THE TIME OF PACKAGING THE CONTENTS ARE SUPPLIED FULLY FUNCTIONAL AND FREE OF DAMAGE SHOULD YOU FIND ANY DAMAGE AS A RESULT OF TRANSIT, PLEASE CONTACT YOUR SUPPLIER IMMEDIATELY.

5. INSTALLATION

I. REMOVE THE APPLIANCE FROM THE PACKAGING. MAKE SURE THAT ALL PROTECTIVE PLASTIC FILM AND COATINGS ARE THOROUGHLY REMOVED FROM ALL SURFACES. TO PREVENT INJURY OR DAMAGE TO THE UNIT, THE APPLIANCE SHOULD BE UNPACKED AND SET UP BY TWO PEOPLE.

2. MAINTAIN A DISTANCE OF 20CM (7 INCHES) BETWEEN THE UNIT AND WALLS OR OTHER OBJECTS FOR VENTILATION. INCREASE THIS DISTANCE IF THE OBSTACLE IS A HEAT SOURCE.

3. LEVEL THE APPLIANCE BY ADJUSTING THE SCREW FEET. IT SHOULD BE PLACED ON THE LEVEL SOLID FLOOR OR BASE TO REDUCE THE VIBRATION AND NOISE.

4. THE TEMPERATURE IN THE PLACE WHERE THE SHOWCASE IS LOCATED MUST BE BETWEEN 10 AND 32°C (CLIMATIC CLASS 4). AVOID LOCATING IT IN DIRECT SUNLIGHT OR NEAR HEAT SOURCE SUCH AS AN OVEN OR A RADIATOR.

5. PLEASE MAKE SURE THE APPLIANCE IS PROPERLY VENTILATED.

6. POWER SUPPLY AND VOLTAGE AT THE OPERATING POINT USED COMPLY WITH THE DETAILS ON THE RATING LABEL. THE PLUG MUST BE ACCESSIBLE AFTER INSTALLATION

7. CORRECTLY CONNECT AND DISCONNECT THE PLUG. WHEN INSERT THE PLUG, IT MUST BE PLUGGED TIGHTLY WHEN PULLING OUT THE PLUG, THE PLUG SHOULD BE HELD SECURELY. NEVER PULL THE SUPPLY CORD DIRECTLY.

8. IF THE SHOWCASE IS TO BE SHUT DOWN FOR LONG PERIOD, SWITCH IT OFF AND DISCONNECT THE PLUG FROM SOCKET OUTLET. CLEAN THE APPLIANCE AND LEAVE THE LID OPEN AND REMOVE THE GN PANS TO PREVENT ODOURS.

9. IMPORTANT! FOR YOUR PERSONAL SAFETY, THIS APPLIANCE MUST BE PROPERLY GROUNDED. THIS APPLIANCE IS EQUIPPED WITH A CORD HAVING A GROUNDING WIRE WITH A GROUNDING PLUG. THE PLUG MUST BE INSERTED INTO AN OUTLET THAT IS PROPERLY GROUNDED AND INSTALLED. CONSULT A QUALIFIED ELECTRICIAN OR SERVICE CENTER IF YOU DO NOT COMPLETELY UNDERSTAND THE GROUNDING INSTRUCTIONS. IF DOUBT EXITS AS TO WHETHER THE APPLIANCE IS PROPERLY GROUNDED, HAVE A QUALIFIED ELECTRICIAN CHECK THE CIRCUIT TO MAKE SURE THE OUTLET IS PROPERLY GROUNDED.

10. IF THE CABLE DOES NOT REACH THE NEAREST SOCKET, EITHER REARRANGE YOUR STORE LAYOUT OR ASK A QUALIFIED ELECTRICIAN TO FIX A NEW SOCKET.

11. IF POWER IS CUT OFF, WAIT FOR AT LEAST 3 MINUTES BEFORE RESTART THE UNIT TO AVOID DAMAGING THE COMPRESSOR.




FITTING THE GLASS PANELS


ATTENTION: RISK OF GLASS PANEL BREAKAGE


NOTE: ENSURE THE HOLE IN THE COLLAR FOR THE GRUB SCREW FACES INWARDS.
NOTE: ENSURE THE SCREW HOLE FURTHEST FROM THE EDGE OF THE PANEL GOES TO THE BACK OF THE APPLIANCE.
NOTE: ENSURE THE SOFT END OF THE GRUB SCREW IS THE END MAKING CONTACT WITH THE GLASS.
NOTE: ENSURE THE SHORT END OF THE BOLT ASSEMBLY IS ON THE OUTSIDE OF THE PANELS.
NOTE: THE GLASS PANEL MUST NOT BE USED AS SHELF.

I. UNPACK THE WOODEN/CARTON BOX CAREFULLY; IT'S RECOMMENDED TO DO THIS WORK WITH TWO PEOPLE.
2. SCREW THE COLLARS TO THE RIM OF THE APPLIANCE.
3. SLOT THE TWO SIDE PANELS INTO THE COLLARS, WITH THE HOLES IN THE GLASS AT THE TOP.
4. SCREW A GRUB SCREW INTO EACH COLLAR TO SECURE THE PANELS.
5. SLOT THE REAR PANEL INTO THE COLLARS, WITH THE HOLES IN THE GLASS AT THE TOP.
6. SCREW A GRUB SCREW INTO EACH COLLAR TO SECURE THE PANEL.
7. SLOT THE PLASTIC BUSHES INTO EACH OF THE HOLES.
8. SCREW THE BRACKETS TO THE INSIDE OF EACH PANEL USING THE BOLT ASSEMBLIES.
9. PLACE THE TOP PANEL ONTO THE BRACKETS, ENSURING ALL HOLES LINE UP.
IO. INSERT THE BUSH AND ATTACH THE TOP PANEL TO THE BRACKETS WITH THE BOLT ASSEMBLIES.

GLASS PANEL ASSEMBLY GUIDE







6. OPERATION

STORING FOOD


TO GET THE BEST RESULTS FROM YOUR APPLIANCE, FOLLOW THESE INSTRUCTIONS:

- ONLY STORE FOODSTUFFS IN THE APPLIANCE WHEN IT HAS REACHED THE CORRECT OPERATING TEMPERATURE.
- ENSURE GN CONTAINER BAYS ARE FULL AT ALL TIMES, EVEN IF THE GN CONTAINERS ARE UNUSED OR EMPTY.
- EMPTY BAYS WILL GREATLY REDUCE EFFICIENCY OF THE APPLIANCE.

TURN ON

1. ENSURE THE POWER SWITCH IS SET TO [O] AND TURN ON AT THE SOCKET.
2. SWITCH ON THE POWER [I]. THE CURRENT TEMPERATURE WITHIN THE APPLIANCE IS DISPLAYED.
3. THE 米 SYMBOL ON THE CONTROL PANEL FLASH FOR 3 MIN FOR ANTI-SHORT CYCLE DELAY BETWEEN THE MOTOR COMPRESSOR STOP AND THE FOLLOWING RESTART.

TEMPERATURE SETTING AND CONTROL



THE FRONT PANEL OF THE THERMOSTAT

1. DEFROSTING LIGHT
2. COMPRESSOR OPERATION LIGHT
3. DIGITAL THERMOSTAT
4. PROGRAMMING KEY (SERVICE AGENT ONLY)
5. TEMPERATURE MODIFICATION KEYS

HOW TO SEE THE SET POINT

1. PUSH AND IMMEDIATELY RELEASE THE SET KEY, THE SET POINT WILL BE SHOWED;
2. PUSH AND IMMEDIATELY RELEASE THE SET KEY OR WAIT ABOUT 5S TO RETURN TO NORMAL VISUALLSATION.

HOW TO CHANGE THE SET POINT

1. PUSH THE SET KEY FOR MORE THAN 2 SECONDS TO CHANGE THE SET POINT VALUE;
2. THE VALUE OF THE SET POINT WILL BE DISPLAYED AND THE "°C" STARTS BLINKING;
3. TO CHANGE THE SET VALUE PUSH THE UP OR DOWN ARROWS WITHIN IOS.
4. TO MEMORISE THE NEW SET POINT VALUE PUSH THE SET KEY AGAIN OR WAITS IOS.

MANUAL DEFROST

THE APPLIANCE WILL AUTOMATICALLY RUN A DEFROST CYCLE EVERY I2 HOURS.

NOTE: THE CYCLE STARTS FROM THE TIME THE APPLIANCE IS INITIALLY POWERED UP.

TO MANUALLY DEFROST THE APPLIANCE:

1. PRESS AND HOLD THE DEFROST BUTTON FOR 5 SECONDS.
2. THE DEFROST CYCLE WILL START IMMEDIATELY AND THE DEFROST LED ILLUMINATES. THE DEFROST WILL LAST A MAXIMUM OF 20 MINUTES.

NOTE: STARTING A MANUAL DEFROST ALSO RESETS THE AUTOMATIC DEFROST TIMER. THE NEXT AUTOMATIC DEFROST WILL START I2 HOURS AFTER THE MANUAL DEFROST HAS FINISHED.

7. CLEANING, CARE & MAINTENANCE

ROUTINE MAINTENANCE

SWITCH OFF AND DISCONNECT FROM THE POWER SUPPLY BEFORE CLEANING.

- CLEAN THE ENCLOSURE AND INTERIOR OF THE APPLIANCE AS OFTEN AS POSSIBLE.
- WASH THE UNIT WITH MOIST CLOTH. NEVER ALLOW THE SWITCH, CONTROL PANEL, CABLE OR PLUG TO GET WET.
- DO NOT USE ABRASIVE CLEANING AGENTS. THESE CAN LEAVE HARMFUL RESIDUES. USE ONLY MILD SOAPY WATER.
- ENSURE THAT NO CLEANING WATER PENETRATES INTO THE ELECTRICAL COMPONENTS.
- MUST NOT BE CLEANED BY A WATER JET.
- ALWAYS WIPE DRY AFTER CLEANING WITH SOFT CLOTH. .
- TAKE CARE WHEN CLEANING THE REAR OF THE APPLIANCE.
- AN AGENT OR QUALIFIED TECHNICIAN MUST CARRY OUT REPAIRS IF REQUIRED.
- IF THE APPLIANCE IS TO BE LEFT INACTIVE FOR LONG PERIODS, UNPLUG THE APPLIANCE AFTER HAVING TURNED THE SWITCH TO OFF POSITION, EMPTY THE REFRIGERATING COMPARTMENT AND CLEAN THOROUGHLY.


SPECIAL MAINTENANCE

ATTENTION: THE INSTRUCTIONS GIVEN IN THE FOLLOWING PARAGRAPH ARE FOR A SKILLED PERSON OR QUALIFIED TECHNICIAN.

PERIODIC OPERATIONS

- PERIODICALLY CLEAN THE CONDENSER USING SUITABLE TOOLS (VACUUM CLEANER OR SOFT BRUSHES)
- CHECK THAT THE ELECTRICAL CONNECTIONS ARE NOT LOOSE.
- CHECK THAT THE THERMOSTAT AND THE SENSOR ARE IN PROPER WORKING ORDER.
- RECOMMEND THAT AN AGENT OR QUALIFIED TECHNICIAN CLEAN THE CONDENSER.

8. WIRING DIAGRAM



9. TROUBLESHOOTING

IF YOUR APPLIANCE DEVELOPS A FAULT, PLEASE CHECK THE FOLLOWING TABLE BEFORE MAKING A CALL TO YOUR RETAILER.

FAULT	PROBABLE CAUSE	ACTION/SOLUTION
THE APPLIANCE IS NOT WORKING	THE UNIT IS NOT SWITCHED ON	CHECK THE UNIT IS PLUGGED IN CORRECTLY AND SWITCHED ON
	PLUG AND LEAD ARE DAMAGED	CALL YOUR AGENT OR QUALIFIED TECHNICIAN
	FUSE IN THE PLUG HAS BLOWN	REPLACE THE FUSE
	POWER SUPPLY	CHECK POWER SUPPLY
	INTERNAL WIRING FAULT	CALL YOUR AGENT OR QUALIFIED TECHNICIAN
THE APPLIANCE TURNS ON, BUT THE TEMPERATURE IS TOO HIGH/LOW	TOO MUCH ICE ON THE EVAPORATOR	DEFROST THE APPLIANCE
	CONDENSER BLOCKED WITH DUST	CALL YOUR AGENT OR QUALIFIED TECHNICIAN
	DOORS ARE NOT SHUT PROPERLY	CHECK DOORS ARE SHUT AND SEALS ARE NOT DAMAGED
	APPLIANCE IS LOCATED NEAR A HEAT SOURCE OR AIR FLOW TO THE CONDENSER IS BEING INTERRUPTED	MOVE THE APPLIANCE TO A MORE SUITABLE LOCATION
	AMBIENT TEMPERATURE IS TOO HIGH	INCREASE VENTILATION OR MOVE APPLIANCE TO A COOLER POSITION
	UNSUITABLE FOODSTUFFS ARE BEING STORED IN THE APPLIANCE	REMOVE ANT EXCESSIVE HOT FOODSTUFF OR BLOCKAGES TO THE FAN
	APPLIANCE IS OVERLOADED	REDUCE THE AMOUNT OF FOOD STORED IN THE APPLIANCE
THE APPLIANCE IS LEAKING WATER	THE APPLIANCE IS NOT PROPERLY LEVELLED	ADJUST THE SCREW FEET TO LEVEL THE APPLIANCE (IF APPLICABLE)
	THE DISCHARGE OUTLET IS BLOCKED	CLEAR THE DISCHARGE OUTLET
	MOVEMENT OF WATER TO DRAIN IS OBSTRUCTED	CLEAR THE FLOOR OF THE APPLIANCE (IF APPLICABLE)
	THE WATER CONTAINER IS DAMAGED	CALL YOUR AGENT OR QUALIFIED TECHNICIAN
	THE DRIP TRAY IS OVERFLOWING	EMPTY THE DRIP TRAY (IF APPLICABLE)
THE APPLIANCE IS UNUSUALLY LOUD	LOOSE NUT/SCREW	CHECK AND TIGHTEN ALL NUTS AND SCREWS
	THE APPLIANCE HAS NOT BEEN INSTALLED IN A LEVEL OR STABLE	CHECK INSTALLATION POSITION AND CHANGE IS NECESSARY

10. DISPOSAL

THE PACKAGING IS DESIGNED TO PROTECT THE APPLIANCE AND INDIVIDUAL COMPONENTS DURING TRANSPORT AND IS MADE OF RECYCLABLE MATERIALS.

PLEASE RETURN THE PACKING MATERIAL TO THE NEAREST OFFICIAL COLLECTION POINT SO THAT THE VARIOUS MATERIALS CAN BE RECYCLED OR REUSED AS FAR AS POSSIBLE AND SO AS TO AVOID THROWING THEM AWAY. OLD APPLIANCE STILL CONTAINS REUSABLE MATERIAL AND SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD OR BULK REFUSE.

BE SURE TO MAKE ANY LOCKS UNUSABLE. IF POSSIBLE REMOVE ANY DOOR(S) AND DISCARD SEPARATELY. REMOVE THE SPRING-ACTION OR BOLT CATCH FROM THE APPLIANCE OR RENDER IT UNUSABLE SO THAT CHILDREN CAN NOT BECOME TRAPPED INSIDE.

PLEASE NOTE THE REFRIGERATION SYSTEM CONTAINS GASES AND REFRIGERANTS WHICH REQUIRE SPECIAL WASTE DISPOSAL. ENSURE THAT THE REFRIGERANT CIRCUIT IS NOT DAMAGED PRIOR TO DISPOSAL. YOU CAN CONTRIBUTE TO ENVIRONMENTAL AWARENESS BY INSISTING ON AN APPROPRIATE NON-POLLUTING METHOD OF DISPOSAL. INFORMATION CONCERNING THE REFRIGERANT AND INSULATION MATERIALS USED CAN BE FOUND ON THE RATING LABEL.

INFORMATION ON COLLECTION DATES OR COLLECTION POINTS CAN BE OBTAINED FROM THE WASTE DISPOSAL AUTHORITIES OR LOCAL COUNCIL.

THE  SYMBOL ON THE PRODUCT OR ITS PACKAGING INDICATES THAT THIS PRODUCT CAN BE TREATED AS HOUSEHOLD WASTE. INSTEAD IT SHALL BE HANDED OVER TO THE APPLIANCABLE COLLECTION POINT FOR THE RECYCLING OF ELECTRICAL AND ELECTRONIC EQUIPMENT. BY ENSURING THIS PRODUCT IS DISPOSED OF CORRECTLY, YOU WILL HELP PREVENT POTENTIAL NEGATIVE CONSEQUENCES FOR THE ENVIRONMENT AND HUMAN HEALTH, WHICH COULD OTHERWISE BE CAUSED BY INAPPROPRIATE WASTE HANDLING OF THIS PRODUCT. FOR MORE DETAILED INFORMATION ABOUT RECYCLING OF THIS PRODUCT, PLEASE CONTACT YOUR LOCAL CITY OFFICE, YOUR HOUSEHOLD WASTE DISPOSAL SERVICE OR THE SHOP WHERE YOU PURCHASED THE PRODUCT.

11. WARRANTY

THE APPLIANCE AND THE COMPONENTS WE PRODUCE ARE GUARANTEED FOR 2 YEARS FROM THE DATE OF PURCHASE AND ANY PART OR PARTS THEREOF, WHICH ARE SHOWN TO THE COMPANY'S SATISFACTION TO BE DEFECTIVE, WILL BE REPLACED FREE OF CHARGE. ANY SUCH FAULTS SHALL NOT, HOWEVER, BE CONSIDERED IF DUE TO INCORRECT USE OF THE PRODUCT RESULTING FROM THE INSTRUCTIONS GIVEN IN THIS HANDBOOK NOT HAVING BEEN FOLLOWED. CHARGES FOR LABOR, TRAVEL AND CARRIAGE ARE NOT COVERED BY THE WARRANTY.

12. COMPLIANCE

PARTS HAVE UNDERGONE STRICT PRODUCT TESTING IN ORDER TO COMPLY WITH REGULATORY STANDARDS AND SPECIFICATIONS SET BY INTERNATIONAL, INDEPENDENT, AND FEDERAL AUTHORITIES. PRODUCTS HAVE BEEN APPROVED TO CARRY THE FOLLOWING SYMBOL:

CE

ALL THE RESPONSIBILITY FOR THE FAILURE TO RESPECT THE EXISTING LECAL STATUTES ARE THE RESPONSIBILITY OF THE OWNER.

RCG015 · CONTENDER 1200MM WIDE REFRIGERATED TOPPING UNIT - 5XI/4GN

RCG016 · CONTENDER 1500MM WIDE REFRIGERATED TOPPING UNIT - 7XI/4GN

RCG017 · CONTENDER 1800MM WIDE REFRIGERATED TOPPING UNIT - 8XI/4GN

RCG018 · CONTENDER 2000MM REFRIGERATED TOPPING UNIT - 10XI/4GN

RCG020 · CONTENDER 1400MM WIDE REFRIGERATED TOPPING UNIT - 6XI/4GN

CONTENDER

STEP UP TO THE PLATE

DISTRIBUTED BY RG DISTRIBUTORS LTD, UNIT 7 JADE BUSINESS PARK, SPRING ROAD, SEAHAM, SR7 9DR. · TEL: 0333 358 3678